## **COMPREHENSIVE SERVICES**

We offer competitive repair and calibration services, as well as easily accessible documentation and free downloadable resources.

## **SELL YOUR SURPLUS**

We buy new, used, decommissioned, and surplus parts from every NI series. We work out the best solution to suit your individual needs.

Sell For Cash Get Credit Receive a Trade-In Deal

## **OBSOLETE NI HARDWARE IN STOCK & READY TO SHIP**

We stock New, New Surplus, Refurbished, and Reconditioned NI Hardware.



**Bridging the gap** between the manufacturer and your legacy test system.

1-800-915-6216



www.apexwaves.com

sales@apexwaves.com

All trademarks, brands, and brand names are the property of their respective owners.

Request a Quote



PXI-6512

Contact: 866-275-6964

support@ni.com



**Board Assembly Part Number(s)** 

Part Number	Description
190359C-01L or later	PXI-6511 INDUSTRIAL 64 SOURCE/SINK DI, BANK ISOLATED DIGITAL INPUT MODULE AND NI-DAQ
190853C-02L or later	NI PXI-6512 INDUSTRIAL 64 SOURCE DO, BANK ISOLATED DIGITAL OUTPUT MODULE AND NI-DAQ

**Manufacturer:** National Instruments

Size

**Volatile Memory** 

User Accessible/ Battery
System Accessible<sup>2</sup> Backup? Purpose Method of Clearing<sup>3</sup>

**NONE** 

Type<sup>1</sup>

**Non-Volatile Memory** 

Type	Size	User Accessible/ System Accessible	Battery Backup		Method of Clearing
EEPROM	IM bits	Yes/Yes	No	The device configuration area is not accessible from any API. The section that stores digital power-up states does have portion that are user accessible.	None available to user /Via API

**Media Storage** 

		User Accessible/	Battery		
Type	Size	System Accessible	Backup?	Purpose	Method of Clearing

**NONE** 

Calibration constants that are stored in device EEPROMs include information for the device's full operating range. Calibration constants do not maintain any unique data for specific configurations at which the device is used unless otherwise specified.

<sup>&</sup>lt;sup>2</sup> Items are designated **No** for the following reason(s):

a) Hardware changes or a unique software tool from National Instruments are required to modify contents of the memory listed.

b) Hardware-modifying software tools are not distributed to customers for any personal access or customization, also known as non-normal use.

<sup>&</sup>lt;sup>3</sup> The designation *None Available to User* indicates that the ability to clear this memory is not available to the user under normal operation. The utilities required to clear the memory are not distributed by National Instruments to customers for normal use.



## **Terms and Definitions**

User Accessible Allows the user to directly write or modify the contents of the memory during normal instrument operation.

**System Accessible** Does not allow the user to access or modify the memory during normal instrument operation. However, system accessible memory may be accessed or modified by background processes. This can be something that is not deliberate by the user and can be a background driver implementation, such as storing application information in RAM to increase speed of use.

**Cycle Power** The process of completely removing power from the device and its components. This process includes a complete shutdown of the PC and/or chassis containing the device; a reboot is not sufficient for the completion of this process.

**Volatile Memory** Requires power to maintain the stored information. When power is removed from this memory, its contents are lost.

**Non-Volatile** Retains its contents when power is removed. This type of memory typically contains calibration or chip configuration information, such as power up states.