COMPREHENSIVE SERVICES

We offer competitive repair and calibration services, as well as easily accessible documentation and free downloadable resources.

SELL YOUR SURPLUS

We buy new, used, decommissioned, and surplus parts from every NI series. We work out the best solution to suit your individual needs.

Sell For Cash Get Credit Receive a Trade-In Deal

OBSOLETE NI HARDWARE IN STOCK & READY TO SHIP

We stock New, New Surplus, Refurbished, and Reconditioned NI Hardware.



Bridging the gap between the manufacturer and your legacy test system.

1-800-915-6216



www.apexwaves.com

sales@apexwaves.com

All trademarks, brands, and brand names are the property of their respective owners.

Request a Quote



cDAQ-9137

SAFETY, ENVIRONMENTAL, AND REGULATORY INFORMATION

NI cDAQ[™]-9137

NI CompactDAQ Eight-Slot Controller with Quad-Core Processor

This document includes compliance precautions and connection information for the NI cDAQ-9137.



Note The guidelines in this document are specific to the NI cDAQ-9137. The other components in the system might not meet the same ratings. Refer to the documentation for each component in the system to determine the safety and EMC guidelines for the entire system.

Safety Guidelines



Caution Do not operate the NI cDAQ-9137 in a manner not specified in this user manual. Product misuse can result in a hazard. You can compromise the safety protection built into the product if the product is damaged in any way. If the product is damaged, return it to National Instruments for repair.



Note Because some C Series modules may have more stringent certification standards than the NI cDAQ-9137, the combined system may be limited by individual component restrictions. Refer to the *NI cDAQ-9137 Specifications* for more details.



Hot Surface This icon denotes that the component may be hot. Touching this component may result in bodily injury.

Safety Voltages

Connect only voltages that are below these limits.

V1 terminal to C terminal	30 VDC maximum, Measurement Category I
V2 terminal to C terminal	30 VDC maximum, Measurement Category I
Chassis ground to C terminal	30 VDC maximum, Measurement Category I

Measurement Category I is for measurements performed on circuits not directly connected to the electrical distribution system referred to as *MAINS* voltage. MAINS is a hazardous live electrical supply system that powers equipment. This category is for measurements of voltages from specially protected secondary circuits. Such voltage measurements include signal levels, special equipment, limited-energy parts of equipment, circuits powered by regulated low-voltage sources, and electronics.





Caution Do not connect the cDAQ-9137 to signals or use for measurements within Measurement Categories II, III, or IV.



Note Measurement Categories CAT I and CAT O are equivalent. These test and measurement circuits are not intended for direct connection to the MAINS building installations of Measurement Categories CAT II, CAT III, or CAT IV.

Safety Guidelines for Hazardous Locations

The NI cDAO-9137 is suitable for use in Class I, Division 2, Groups A, B, C, D, T4 hazardous locations; Class I, Zone 2, AEx nA IIC T4 and Ex nA IIC T4 hazardous locations; and nonhazardous locations only. Follow these guidelines if you are installing the NI cDAQ-9137 in a potentially explosive environment. Not following these guidelines may result in serious injury or death.



Caution Do not disconnect the power supply wires and connectors from the controller unless power has been switched off.



Caution Do not disconnect I/O-side wires or connectors unless power has been switched off or the area is known to be nonhazardous.



Caution Do not remove modules unless power has been switched off or the area is known to be nonhazardous.



Caution Substitution of components may impair suitability for Class I, Division 2.



Caution For Division 2 and Zone 2 applications, install the system in an enclosure rated to at least IP54 as defined by IEC/EN 60079-15.



Caution Do not insert or remove SD cards unless power has been switched off or the area is known to be nonhazardous.



Caution The USB host ports, USB device port, mini DisplayPort, and SD card slot require the retention accessories listed in the following table for hazardous locations. All cables must be used in a conduit or cable gland to wire to a nonhazardous location. Do not disconnect a cable unless the cDAO-9137 is powered off or the area is known to be nonhazardous.

Table 1. Hazardous Location Retention Accessories

Port	Required Accessory	Part Number
USB Host Port	NI Industrial USB Extender Cable	152166-xx
USB Device Port	NI Locking USB Cable	157788-01

 Table 1. Hazardous Location Retention Accessories (Continued)

Port	Required Accessory	Part Number
Mini DisplayPort	Mini DisplayPort Cable Retention Bracket	156866-01
SD Card Slot	SD Door Kit	783660-01

Special Conditions for Hazardous Locations Use in Europe and Internationally

The cDAQ-9137 has been evaluated as Ex nA IIC T4 Gc equipment under DEMKO Certificate No. 12 ATEX 1202658X and is IECEx UL 14.0089X certified. Each device is marked © II 3G and is suitable for use in Zone 2 hazardous locations, in ambient temperatures of -20 °C \leq Ta \leq 55 °C.



Caution You must make sure that transient disturbances do not exceed 140% of the rated voltage.



Caution The system shall only be used in an area of not more than Pollution Degree 2, as defined in IEC 60664-1.



Caution The system shall be mounted in an ATEX/IECEx-certified enclosure with a minimum ingress protection rating of at least IP54 as defined in IEC/EN 60079-15.



Caution The enclosure must have a door or cover accessible only by the use of a tool.

Power Requirements



Caution The protection provided by the NI cDAO-9137 can be impaired if it is used in a manner not described in the user documentation.



Note Some C Series modules have additional power requirements. For more information about C Series module power requirements, refer to the C Series module(s) documentation.



Note Sleep mode for C Series modules is not supported in the NI cDAQ-9137.

Voltage input range	9 to 30 V (measured at the NI cDAQ-9137
	power connector)
Maximum power consumption ¹	46 W
Recommended power supply	100 W, 24 VDC

¹ Includes maximum 1 W module load per slot across rated temperature and product variations.



Note The maximum power consumption specification is based on a fully populated system running a high-stress application at elevated ambient temperature, and with all C Series modules and USB devices consuming the maximum allowed power.

Power Connector Characteristics

Screw-terminal wiring	
Gauge	0.5 mm ² to 2.1 mm ² (20 AWG to 14 AWG) copper conductor wire
Wire strip length	6 mm (0.24 in.) of insulation stripped from the end
Temperature rating	85 °C
Torque for screw terminals	0.20 N · m to 0.25 N · m (1.8 lb · in. to 2.2 lb · in.)
Wires per screw terminal	One wire per screw terminal
Connector securement	
Securement type	Screw flanges provided
Torque for screw flanges	0.20 N · m to 0.25 N · m (1.8 lb · in. to 2.2 lb · in.)

Wiring Power to the NI cDAQ-9137

The NI cDAQ-9137 requires an external power source as described in the *Power Connector Characteristics* section. The NI cDAQ-9137 filters and regulates the supplied power and provides power to all of the I/O modules. The NI cDAQ-9137 has a primary power input, V1, and a secondary power input, V2. The POWER LED on the front panel identifies the power input in use. When the LED is lit green, V1 is in use; when the LED is lit yellow, V2 is in use.



Caution Do not connect V2 to a DC MAINS supply or to any supply requiring a connecting cable longer than 3 m (10 ft). A DC MAINS supply is a local DC electricity supply network in the infrastructure of a site or building.

Complete the following steps to connect a power source to the NI cDAQ-9137.

- 1. Make sure the power source is turned off.
- 2. Install the ferrite (National Instruments part number 711849-01, included in the shipping kit) across the negative and positive leads of the power source, approximately 50 mm to 75 mm (2 in. to 3 in.) from the ends of the leads near the NI cDAQ-9137.
- Loosen the connector screw flanges and remove the power screw terminal connector plug from the NI cDAQ-9137.



Note Do not tighten or loosen the terminal screws on the power connector while the power is on.

4. Connect the positive lead of the primary power source to the V1 terminal of the power connector plug and tighten the terminal screw.

- Connect the negative lead of the primary power source to one of the C terminals of the power screw terminal connector plug and tighten the terminal screw.
- Optionally, you can connect the positive lead of a secondary power source to the 6. V2 terminal and the negative lead to the other C terminal.
- Install the power connector plug on the front panel of the NI cDAQ-9137 and tighten the 7 connector screw flanges.
- Turn on the external power source(s). 8

The cDAQ controller uses V1 if the voltage across V1 and C is 9 V or greater. If the V1-to-C voltage drops below 9 V, the NI cDAO-9137 switches to V2. If the V2-to-C voltage is less than 9 V, operation may be interrupted.



Note If the NI cDAQ-9137 is using V1 and a secondary power source is connected to V2, there is a small leakage current on V2. The leakage current depends on the V2-to-C voltage. Refer to the NI cDAQ-9137 Specifications for nominal values of this leakage current

If the power source is connected to the power connector using long wiring with high DC resistance, the voltage at the power connector may be significantly lower than the specified voltage of the power source.

The C terminals are internally connected to each other but are not connected to chassis ground. You can connect the C terminals to chassis ground externally. Refer to the *Power* Requirements section for information about the power supply input range. Refer to the Safety Guidelines section for information about the maximum voltage from terminal to chassis ground.



Caution Removing power without shutting down the NI cDAQ-9137 for Windows can corrupt the embedded Windows system drive.

Preparing the Environment

Ensure that the environment you are using the NI cDAQ-9137 in meets the following specifications.

Temperature (IEC 60068-2-1 and IEC 60068-2-2)		
Operating	-20 to 55 °C	
Storage	-40 to 85 °C	



Caution Failure to follow the mounting instructions in the NI cDAQ-9132/9133/9134/9135/9136/9137 User Manual can cause temperature derating. For more information about mounting configurations and temperature derating, go to ni.com/info and enter Info Code cdaqmounting.

Pollution Degree (IEC 60664)	2
Maximum altitude	5,000 m

Indoor use only.



Note Refer to the *NI cDAQ-9137 Specifications* for complete specifications.

Electromagnetic Compatibility Guidelines

This product was tested and complies with the regulatory requirements and limits for electromagnetic compatibility (EMC) stated in the product specifications. These requirements and limits provide reasonable protection against harmful interference when the product is operated in the intended operational electromagnetic environment.

This product is intended for use in industrial locations. However, harmful interference may occur in some installations, when the product is connected to a peripheral device or test object, or if the product is used in residential or commercial areas. To minimize interference with radio and television reception and prevent unacceptable performance degradation, install and use this product in strict accordance with the instructions in the product documentation.

Furthermore, any changes or modifications to the product not expressly approved by National Instruments could void your authority to operate it under your local regulatory rules.



Caution To ensure the specified EMC performance, product installation requires either special considerations or user-installed add-on devices. Refer to the *NI cDAQ-9132/9133/9134/9135/9136/9137 User Manual* for further information.



Caution To ensure the specified EMC performance, operate this product only with shielded cables and accessories. Note that the input DC power cables may be unshielded.



Caution To ensure the specified EMC performance, do not connect V2 to a DC MAINS supply or to any supply requiring a connecting cable longer than 3 m (10 ft). A DC MAINS supply is a local DC electricity supply network in the infrastructure of a site or building.



Caution To ensure the specified EMC performance, the length of any cable connected to the video and USB host ports must be no longer than 3 m (10 ft). The length of any cable connected to the RS-232 port must be no longer than 30 m (100 ft).



Caution The USB device port is intended for use in device configuration, application deployment, debug, and maintenance.

Special Conditions for Marine Applications

Some products are Lloyd's Register (LR) Type Approved for marine (shipboard) applications. To verify Lloyd's Register certification for a product, visit ni.com/certification and search for the LR certificate, or look for the Lloyd's Register mark on the product.



Caution In order to meet the EMC requirements for marine applications, install the product in a shielded enclosure with shielded and/or filtered power and input/output ports. In addition, take precautions when designing, selecting, and installing measurement probes and cables to ensure that the desired EMC performance is attained.

Connecting to the cDAQ Controller

Connecting to the Network through the Ethernet Port



Caution To prevent data loss and to maintain the integrity of your Ethernet installation, do not use a cable longer than 100 m.

Connecting to the Mini DisplayPort Connector



Caution Do not hot-swap mini DisplayPort devices while the NI cDAQ-9137 is in a hazardous location or connected to high voltages.

Connecting to the USB Host Ports

Install a noise-suppression ferrite (National Instruments part number 711849-01, included in the shipping kit) around all external USB cables attached to the USB host ports to ensure that your device meets all EMC standards applicable to your country. The ferrite should be installed so that it is approximately 50 to 75 mm (2 to 3 in.) from the end of the cable that plugs into the USB host port. The ferrite should accommodate both USB cables depending on cable diameter.



Caution Do not hot-swap USB devices while the NI cDAQ-9137 is in a hazardous location or connected to high voltages. If the NI cDAQ-9137 is not in a hazardous location, you can connect and disconnect USB devices without affecting operation.

Connecting to the USB Device Port



Caution National Instruments requires a locking USB cable, such as part number 157788-01, in order to meet the shock and vibration specifications of this product.



Caution Do not hot-swap USB devices while the NI cDAQ-9137 is in a hazardous location or connected to high voltages. If the NI cDAQ-9137 is not in a hazardous location, you can connect and disconnect USB devices without affecting operation.

Using the SD Card Removable Storage



Caution You must use the SD card slot cover to protect the SD card in hazardous locations.



Caution Do not insert or remove SD cards unless power has been switched off or the area is known to be nonhazardous.

Where to Go Next

The following documents contain information that you may find helpful as you use this document:

- NI cDAO-9132/9133/9134/9135/9136/9137 User Manual
- NI cDAQ-9137 Specifications

Worldwide Support and Services

NI corporate headquarters is located at 11500 North Mopac Expressway, Austin, Texas, 78759-3504. NI also has offices located around the world. For telephone support in the United States, create your service request at *ni.com/support* or dial 1 866 ASK MYNI (275 6964). For telephone support outside the United States, visit the *Worldwide Offices* section of *ni.com/niglobal* to access the branch office websites, which provide up-to-date contact information, support phone numbers, email addresses, and current events.

Refer to the *NI Trademarks and Logo Guidelines* at ni.com/trademarks for information on NI trademarks. Other product and company names mentioned herein are trademarks or trade names of their respective companies. For patents covering NI products/technology, refer to the appropriate location: *Help»Patents* in your software, the patents. txt file on your media, or the *National Instruments Patent Notice* at ni.com/patents. You can find information about end-user license agreements (EULAs) and third-party legal notices in the readme file for your NI product. Refer to the *Export Compliance Information* at ni.com/legal/export-compliance for the NI global trade compliance policy and how to obtain relevant HTS codes, ECCNs, and other import/export data. NI MAKES NO EXPRESS OR IMPLIED WARRANTIES AS TO THE ACCURACY OF THE INFORMATION CONTAINED HEREIN AND SHALL NOT BE LIABLE FOR ANY ERRORS, U.S. Government Customers: The data contained in this manual was developed at private expense and is subject to the applicable limited rights and restricted data rights as set forth in FAR 52.227-714, DFAR 252.227-7014, and DFAR 252.227-7015.

© 2015 National Instruments. All rights reserved.