COMPREHENSIVE SERVICES

We offer competitive repair and calibration services, as well as easily accessible documentation and free downloadable resources.

SELL YOUR SURPLUS

We buy new, used, decommissioned, and surplus parts from every NI series. We work out the best solution to suit your individual needs. We Sell For Cash We Get Credit We Receive a Trade-In Deal

OBSOLETE NI HARDWARE IN STOCK & READY TO SHIP

We stock New, New Surplus, Refurbished, and Reconditioned NI Hardware.

APEX WAVES

Bridging the gap between the manufacturer and your legacy test system.

1-800-915-6216
www.apexwaves.com
sales@apexwaves.com

All trademarks, brands, and brand names are the property of their respective owners.

Request a Quote CLICK HERE CRIO-9031



Manufacturer: National Instruments

Board Assembly Part Numbers (Refer to Procedure 1 for identification procedure):

| Part Number and Revision | Description |
|--------------------------|-------------|
| 156502A-01L or later | cRIO-9031 |

Volatile Memory

| | | | Battery | User ¹ | System | Sanitization |
|-----------------------|-------------|----------|---------|-------------------|------------|--------------|
| Target Data | Туре | Size | Backup | Accessible | Accessible | Procedure |
| System Memory | DDR3-SDRAM | 1 GB | No | Yes | Yes | Cycle Power |
| LabVIEW and User Data | FPGA RAM | Kintex-7 | No | Yes | Yes | Cycle Power |
| | | 7K70T | | | | |
| CPLD Memory | CPLD-SDRAM | 51 Mb | No | No | Yes | Cycle Power |
| Real-Time Clock Data | SoC RTC RAM | 242 | Yes | Yes | Yes | Procedure 2 |
| | | Bytes | | | | |

Non-Volatile Memory (incl. Media Storage)

| Target Data | Туре | Size | Battery Backup | User Accessible | System Accessible | Sanitization Procedure |
|--------------------------|-----------------|-----------|-------------------|--------------------|----------------------|---------------------------|
| Primary storage | Disk-on- | 4 GB | No | | | |
| Safemode | Chip | | | No | Yes | None |
| Operating System | _ | | | No | Yes | Procedure 3 |
| • User Data | | | | Yes | Yes | Procedure 3 |
| FPGA storage | FLASH | 32 Mb | No | | | |
| FPGA Firmware | | | | No | Yes | None |
| • User FPGA VI Bitstream | | | | Yes | Yes | Procedure 4 |
| General Logic | CPLD | 0.47 Mb | No | No | Yes | None |
| Firmware | Ethernet NVM | 8 Mb | No | No | Yes | None |
| Describes DDR3L memory | SPD EEPROM | 256 bytes | No | No | Yes | None |
| BIOS firmware | FLASH | 8 MB | No | No | Yes | None |

¹ Refer to *Terms and Definitions* section for clarification of *User* and *System Accessible*



Procedures

Procedure 1 – Board Assembly Part Number identification:

To determine the Board Assembly Part Number and Revision, check the top left corner of the white label on the bottom of the module (15xxxx<REV>-xxL).

Procedure 2 – SoC RTC RAM (Real-Time Clock Data):

The battery-backed Real-Time Clock data can be cleared from the SoC RTC RAM using the CMOS reset button. To clear the Real-Time Clock data, perform the following steps:

- 1. Disconnect power form the cRIO controller.
- 2. Locate the CMOS reset button in the center of the cRIO backplane.
- 3. Press the CMOS reset button and hold it from 1 second.

Procedure 3 – Primary Storage Disk-on-Chip (OS and User Data):

The Primary Storage DoC can be reformatted to clear the OS and User Data areas. The format operation is a "quick format" that re-initializes the file table, thereby making the existing files inaccessible. Format the drive for this NI Linux Real-Time target by performing one of the following steps:

- 1. Right-click the controller in MAX and click on "Format Drive".
- 2. Issue the nisystemformat command via a serial console local connection or SSH remote connection. Visit ni.com/info and enter the info code *format* for details.
- 3. Write a .VI that invokes the Format VI using the System Configuration API for the controller.

Procedure 4 – FPGA Storage Flash (User FPGA Bitstream):

The User FPGA Bitstream in the FPGA Storage Flash can be cleared using NI-RIO Device Setup. To clear the bitstream from the flash, perform the following steps:

- 1. Add the cRIO target to your LabVIEW project by right-clicking on the project and selecting New » Targets and Devices and selecting your cRIO.
- 2. Right-click on the FPGA project item and select RIO Device Setup.
- 3. In the Advanced section, select Erase Bitfile on Flash.



Terms and Definitions

Cycle Power:

The process of completely removing power from the device and its components and allowing for adequate discharge. This process includes a complete shutdown of the PC and/or chassis containing the device; a reboot is not sufficient for the completion of this process.

Volatile Memory:

Requires power to maintain the stored information. When power is removed from this memory, its contents are lost. This type of memory typically contains application specific data such as capture waveforms.

Non-Volatile Memory:

Power is not required to maintain the stored information. Device retains its contents when power is removed. This type of memory typically contains information necessary to boot, configure, or calibrate the product or may include device power up states.

User Accessible:

The component is read and/or write addressable such that a user can store arbitrary information to the component from the host using a publicly distributed NI tool, such as a Driver API, the System Configuration API, or MAX.

System Accessible:

The component is read and/or write addressable from the host without the need to physically alter the product.

Clearing:

Per *NIST Special Publication 800-88 Revision 1*, "clearing" is a logical technique to sanitize data in all User Accessible storage locations for protection against simple non-invasive data recovery techniques using the same interface available to the user; typically applied through the standard read and write commands to the storage device.

Sanitization:

Per *NIST Special Publication 800-88 Revision 1*, "sanitization" is a process to render access to "Target Data" on the media infeasible for a given level of effort. In this document, clearing is the degree of sanitization described.