

COMPREHENSIVE SERVICES

We offer competitive repair and calibration services, as well as easily accessible documentation and free downloadable resources.

SELL YOUR SURPLUS

We buy new, used, decommissioned, and surplus parts from every NI series. We work out the best solution to suit your individual needs.

 Sell For Cash  Get Credit  Receive a Trade-In Deal

OBSOLETE NI HARDWARE IN STOCK & READY TO SHIP

We stock **New**, **New Surplus**, **Refurbished**, and **Reconditioned** NI Hardware.



Bridging the gap between the manufacturer and your legacy test system.

 1-800-915-6216

 www.apexwaves.com

 sales@apexwaves.com

All trademarks, brands, and brand names are the property of their respective owners.

Request a Quote

 **CLICK HERE**

PXIe-6672

CALIBRATION PROCEDURE

NI PXIe-6672

This document describes how to write a calibration procedure for the 10 MHz oscillator frequency of the NI PXIe-6672 timing and synchronization module.

Contents

| | |
|-------------------------------|----|
| Conventions | 1 |
| Software | 2 |
| Documentation | 2 |
| Calibration Interval | 3 |
| Password | 3 |
| Test Equipment | 3 |
| Test Conditions | 3 |
| Calibration Procedure | 4 |
| Initial Setup | 4 |
| Verification | 4 |
| Measuring the Frequency | 6 |
| Adjustment | 9 |
| Reverification | 13 |

Conventions

The following conventions apply to this document:

»

The » symbol leads you through nested menu items and dialog box options to a final action. The sequence **File»Page Setup»Options** directs you to pull down the **File** menu, select the **Page Setup** item, and select **Options** from the last dialog box.



This icon denotes a note, which alerts you to important information.



This icon denotes a caution, which advises you of precautions to take to avoid injury, data loss, or a system crash. When this symbol is marked on a product, refer to the *Read Me First: Safety and Radio-Frequency Interference* for information about precautions to take.



When symbol is marked on a product, it denotes a warning advising you to take precautions to avoid electrical shock.



When symbol is marked on a product, it denotes a component that may be hot. Touching this component may result in bodily injury.

bold

Bold text denotes items that you must select or click in the software, such as menu items and dialog box options. Bold text also denotes parameter names.

italic

Italic text denotes variables, emphasis, a cross-reference, or an introduction to a key concept. Italic text also denotes text that is a placeholder for a word or value that you must supply.

monospace

Text in this font denotes text or characters that you should enter from the keyboard, sections of code, programming examples, and syntax examples. This font is also used for the proper names of disk drives, paths, directories, programs, subprograms, subroutines, device names, functions, operations, variables, filenames, and extensions.

monospace italic

Italic text in this font denotes text that is a placeholder for a word or value that you must supply.

Software

This calibration procedure requires NI-Sync and NI-VISA. NI-Sync and NI-VISA support a number of application development environments (ADEs) and programming languages, including LabVIEW, LabWindows™/CVI™, and Microsoft Visual C++. When you install the drivers, you need to install support for only the ADE or programming language you are using. The illustrations in this document show the LabVIEW code for implementing calibration steps using NI-Sync and NI-VISA.

Documentation

You need the *NI-Sync User Manual* to calibrate the NI PXIe-6672.

The *NI-Sync User Manual* contains detailed information about using the NI-Sync driver, including information about installing NI-Sync and creating applications that use the NI-Sync driver. These sources, along with this document, are your primary references for writing your calibration utility. You also can refer to the documentation for the programming language or application development environment you are using. For further information about the device you are calibrating, refer to the *NI PXIe-6672 User Manual*.

Calibration Interval

The measurement requirements of the application determine how often you should calibrate the device to ensure its accuracy. National Instruments recommends that you calibrate the NI PXIe-6672 *yearly*. You may want to shorten this interval based on the application demands.

Password

The default password for password-protected operations is `NI`.

Test Equipment

Calibrating the NI PXIe-6672 requires the following equipment.

| Equipment | Recommended Model | Requirements |
|---------------------|------------------------|--|
| 10 MHz clock source | Symmetricon/Datum 8040 | Accurate to within 150 parts-per-billion (ppb) |
| BNC-SMB cable | — | — |
| SMB-SMB cable | — | — |

Test Conditions

Follow these guidelines to optimize connections and test conditions during the calibration procedure:

- Install the NI PXIe-6672 in the system timing slot of the PXI Express chassis. The calibration procedure requires features of PXI that are accessible only in the system timing slot.
- Maintain a temperature of approximately 25 °C.
- Keep relative humidity below 80 percent.
- Use shielded copper wire for all cable connections to the device.
- Allow a warm-up time of at least 15 minutes for the NI PXIe-6672 to ensure the measurement circuitry is at a stable operating temperature.
- Keep PXI chassis filters clean and fan speed set to High.

Calibration Procedure

The steps used in the calibration procedure are as follows:

1. Initial setup.
2. Verification.
3. Adjustment.
4. Reverification.

Initial Setup

Complete the following steps to set up the NI PXIe-6672 for calibration.

1. Make sure all components involved in the calibration procedure are powered off.
2. Install the NI PXIe-6672 board into the system timing slot of your chassis.
3. Power on the PXI chassis first, and then the external equipment.
4. Make sure that all the appropriate driver and application software is installed on the host computer.
5. Configure the hardware with Measurement & Automation Explorer (MAX). Refer to the *NI PXIe-6672 Installation Guide* for details about configuring the PXI equipment.

Verification

The following steps outline the procedure for measuring the 10 MHz oscillator frequency on the NI PXIe-6672 and determining whether the device requires adjustment to meet the published specifications.


Connecting the Clock Source

1. Connect the accurate 10 MHz source to the ClkIn connector on the NI PXIe-6672.
2. Program the NI PXIe-6672 to route the ClkIn signal to PXI_Clk10In without using its 10 MHz PLL by completing steps a–d.




Note Use the data in the C function call reference as inputs to your LabVIEW VI where applicable.


- a. Call niSync Initialize VI to set up a handle for the device.

| LabVIEW Block Diagram | NI-SYNC C Function Call |
|--|--|
|  <p>The diagram shows the 'niSync Initialize VI' block. It has an input 'resource name' with a value of 'abc'. It has an output 'instrument handle out'. There is an 'error out' terminal. A 'reset device' control is connected to the 'niSync Initialize VI' block.</p> | <p>Call <code>niSync_init</code> with the following parameters:</p> <p>resourceName: Dev1 idQuery: NULL resetDevice: VI_TRUE vi: *SessionHandle</p> |


- b. Set a writable NI-Sync property node to pass FALSE to the Use PLL? attribute.

| LabVIEW Block Diagram | NI-SYNC C Function Call |
|--|--|
|  <p>The diagram shows a 'Property Node' block. It has an input 'reference in' and an output 'reference out'. It has an input 'error in' and an output 'error out'. The 'Property Node' is set to 'niSync' and the 'Use PLL?' attribute is set to FALSE. A 'Clk Properties: Use PLL?' control is connected to the 'Property Node'.</p> | <p>Call <code>niSync_SetAttributeViBoolean</code> with the following parameters:</p> <p>vi: "<SessionHandle>" terminalName: "" attributeID: NISYNC_ATTR_CLKIN_USE_PLL attributeValue: VI_FALSE</p> |

- c. Call niSync Connect Clock Terminals VI to connect ClkIn to PXI_Clk10_In.

| LabVIEW Block Diagram | NI-SYNC C Function Call |
|---|--|
|  <p>The diagram shows the 'niSync Connect Clock Terminals VI' block. It has an input 'instrument handle in' and an output 'instrument handle out'. It has two input terminals: 'source terminal' set to 'ClkIn' and 'destination terminal' set to 'PXI_Clk10_In'. It has an 'error in (no error)' input and an 'error out' output.</p> | <p>Call <code>niSync_ConnectClkTerminals</code> with the following parameters:</p> <p>vi: "<SessionHandle>" sourceTerminal: NISYNC_VAL_CLKIN destinationTerminal: NISYNC_VAL_CLK10</p> |


- d. Call niSync Close VI to close the handle.

| LabVIEW Block Diagram | NI-SYNC C Function Call |
|---|---|
|  <p>The diagram shows a LabVIEW block diagram for the niSync Close VI. It features an 'instrument handle in' terminal (I/O) connected to the 'niSync' input of the 'niSync Close.vi' block. The block has an 'error in (no error)' terminal connected to the 'Error In' input of the 'niSync' block. The 'niSync' block has an 'error out' terminal connected to the 'Error Out' output of the 'niSync' block.</p> | <p>Call <code>niSync_close</code> with the following parameter:</p> <p>vi: "<SessionHandle>"</p> |


Measuring the Frequency

Complete the following procedure to measure the frequency of the onboard clock source.


1. Connect the **ClkOut** terminal to the PFI 0 terminal by using an SMB-to-SMB cable.
2. Complete steps a–d to program the board to connect the onboard oscillator to ClkOut. Be sure to use the high-gain setting for clock out.
 - a. Call niSync Initialize VI to set up a handle for the device.

| LabVIEW Block Diagram | NI-SYNC C Function Call |
|---|---|
|  <p>The diagram shows a LabVIEW block diagram for the niSync Initialize VI. It features a 'resource name' terminal (I/O) with the value 'abc' connected to the 'Resource Name' input of the 'niSync Initialize.vi' block. The block has a 'reset device' terminal connected to the 'Reset Device' input of the 'niSync' block. The 'niSync' block has an 'instrument handle out' terminal (I/O) connected to the 'Instrument Handle Out' output of the 'niSync' block. The 'niSync' block also has an 'error out' terminal connected to the 'Error Out' output of the 'niSync' block.</p> | <p>Call <code>niSync_init</code> with the following parameters:</p> <p>resourceName: Dev1 idQuery: NULL (ignored) resetDevice: VI_FALSE vi: *SessionHandle</p> |


- b. Set a writable NI-Sync property node to pass TRUE to the **ClkOut Gain Enable** attribute.

| LabVIEW Block Diagram | NI-SYNC C Function Call |
|--|--|
|  <p>The diagram shows a LabVIEW block diagram for the niSync SetAttributeViBoolean VI. It features a 'reference in' terminal (I/O) connected to the 'Reference In' input of the 'niSync' block. The 'niSync' block has an 'error in' terminal connected to the 'Error In' input of the 'niSync' block. The 'niSync' block has a 'Property Node' terminal connected to the 'Property Node' input of the 'niSync' block. The 'Property Node' block has a 'ClkOut Gain Enable' terminal connected to the 'ClkOut Gain Enable' input of the 'niSync' block. The 'niSync' block has a 'reference out' terminal (I/O) connected to the 'Reference Out' output of the 'niSync' block. The 'niSync' block also has an 'error out' terminal connected to the 'Error Out' output of the 'niSync' block. The 'Clk Properties: ClkOut Gain Enable' block has a 'ClkOut Gain Enable' terminal connected to the 'ClkOut Gain Enable' input of the 'niSync' block.</p> | <p>Call <code>niSync_SetAttributeViBoolean</code> with the following parameters:</p> <p>vi: "<SessionHandle>" terminalName: "" attributeID: NISYNC_ATTR_CLKOUT_GAIN_ENABLE attributeValue: VI_TRUE</p> |


- c. Call niSync Connect Clock Terminals VI to connect the oscillator to ClkOut.

| LabVIEW Block Diagram | NI-SYNC C Function Call |
|---|--|
|  | <p>Call niSync_ConnectClkTerminals with the following parameters:</p> <p>vi: "<SessionHandle>"</p> <p>sourceTerminal: NISYNC_VAL_OSCILLATOR</p> <p>destinationTerminal: NISYNC_VAL_CLKOUT</p> |


- d. Call niSync Close VI to close the session handle.

| LabVIEW Block Diagram | NI-SYNC C Function Call |
|---|--|
|  | <p>Call niSync_close with the following parameter:</p> <p>vi: "<SessionHandle>"</p> |


3. Complete steps a–c to measure the oscillator frequency through PFI 0.
- a. Call niSync Initialize VI to set up a handle for the device.

| LabVIEW Block Diagram | NI-SYNC C Function Call |
|---|--|
|  | <p>Call niSync_init with the following parameters:</p> <p>resourceName: Dev1</p> <p>idQuery: NULL</p> <p>resetDevice: VI_FALSE</p> <p>vi: *SessionHandle</p> |

- b. Call niSync Measure Frequency VI to measure the frequency of the oscillator.

| LabVIEW Block Diagram | NI-SYNC C Function Call |
|---|--|
|  | <p>Call niSync_MeasureFrequency with the following parameters:</p> <p>vi: "<SessionHandle>"</p> <p>sourceTerminal: NISYNC_VAL_OSCILLATOR</p> <p>duration: 0.5</p> <p>actualDuration: *actualDuration</p> <p>measuredFrequency: *measuredFrequency</p> <p>error: *error</p> |

- c. Call niSync Close VI to close the session handle.

| LabVIEW Block Diagram | NI-SYNC C Function Call |
|---|--|
|  | <p>Call niSync_close with the following parameter:</p> <p>vi: "<SessionHandle>"</p> |

4. Compare the measured frequency to the device specifications.

To determine if the device under test meets its specifications, you must compare the measured frequency obtained in Step 3 of [Measuring the Frequency](#) with the specified accuracy. Table 1 shows the frequency range that is acceptable according to the published specifications for the NI PXIe-6672.

Table 1. Acceptable Frequency Ranges

| Device | Specified Accuracy | Acceptable Frequency Range | |
|---------------------|--------------------|----------------------------|---------------|
| | | Low Limit | High Limit |
| NI PXIe-6672 (TCXO) | ±2.5 ppm | 9,999,975 Hz | 10,000,025 Hz |

If the measured value is within the low-limit and high-limit range listed under the *Acceptable Frequency Range*, the board is calibrated correctly.


Adjustment

If the accuracy of the 10 MHz oscillator is outside the specified range for the product, the device is out of calibration. A programmable voltage controls the oscillator frequency. By varying this voltage and precisely measuring the frequency, you can find a voltage that gives a frequency as close as possible to 10 MHz.


1. Complete steps a–c to set the oscillator control voltage. The range of acceptable voltage values is 0.0 V to 4.095 V with frequency increasing as voltage increases. Use a control voltage of 2.0475 V, which is in the middle of the valid range, as a starting point.
 - a. Call niSync Initialize VI to set up a handle for the device.

| LabVIEW Block Diagram | NI-SYNC C Function Call |
|-----------------------|---|
| | <p>Call <code>niSync_init</code> with the following parameters:</p> <p>resourceName: Dev1 idQuery: NULL resetDevice: VI_FALSE vi: *SessionHandle</p> |

- b. Set a writable NI-Sync property node to pass the constant **2.0475** to the **Oscillator Voltage** attribute.

| LabVIEW Block Diagram | NI-SYNC C Function Call |
|---|--|
|  | <p>Call <code>niSync_SetAttributeViBoolean</code> with the following parameters:</p> <p>vi: "<SessionHandle>" terminalName: "" attributeID: NISYNC_ATTR_OSCILLATOR_VOLTAGE attributeValue: 2.0475</p> |

- c. Call `niSync Close VI` to close the session handle.


| LabVIEW Block Diagram | NI-SYNC C Function Call |
|---|---|
|  | <p>Call <code>niSync_close</code> with the following parameter:</p> <p>vi: "<SessionHandle>"</p> |

Proceed with the following steps to find the correct oscillator control voltage.


- After setting the control voltage, measure the frequency again with the NI-Sync Measure Frequency VI to measure PFI 0, as shown in Step 3 of the *Measuring the Frequency* section.

Complete steps a–c to measure PFI 0.


- a. Call `niSync Initialize VI` to set up a handle for the device.

| LabVIEW Block Diagram | NI-SYNC C Function Call |
|---|---|
|  | <p>Call <code>niSync_init</code> with the following parameters:</p> <p>resourceName: Dev1 idQuery: NULL resetDevice: VI_FALSE vi: *SessionHandle</p> |

- b. Call niSync Measure Frequency VI to measure the frequency of the oscillator.

| LabVIEW Block Diagram | NI-SYNC C Function Call |
|---|--|
|  | <p>Call niSync_MeasureFrequency with the following parameters:</p> <p>vi: "<SessionHandle>"</p> <p>sourceTerminal: NISYNC_VAL_OSCILLATOR</p> <p>duration: 0.5</p> <p>actualDuration: *actualDuration</p> <p>measuredFrequency: *measuredFrequency</p> <p>error: *error</p> |


- c. Call niSync Close VI to close the session handle.

| LabVIEW Block Diagram | NI-SYNC C Function Call |
|---|--|
|  | <p>Call niSync_close with the following parameter:</p> <p>vi: "<SessionHandle>"</p> |


3. Compare the measured frequency to the device specifications.
4. If the measured frequency is still outside of the specified limit, repeat steps 1–3 of the *Adjustment* section until the measured value falls within the acceptable frequency range for your module, as shown in Table 1, *Acceptable Frequency Ranges*.
5. Commit the calibration values to the Calibration EEPROM using the following procedure.
 - a. Call niSync Initialize External Calibration VI to initialize the process.




Note NI is the default user password. If you have changed the calibration password, use your user-selected calibration password in place of NI.

| LabVIEW Block Diagram | NI-SYNC C Function Call |
|---|--|
|  <p>The diagram shows the 'niSync Initialize External Calibration.vi' block. It has three input terminals: 'resource name ("")' with a text box containing 'abc', 'password' with a text box containing 'NI', and 'instrument handle out' with a numeric control set to 170. It has two output terminals: 'error out' and 'instrument handle out' (which is also the output of the block).</p> | <p>Call niSync_InitExtCal with the following parameters:</p> <p>resourceName: "<MAX ID>" password: NI calibrationInstrumentHandle: *SessionHandle</p> |

- b. Call niSync Adjust Oscillator Voltage VI to adjust the voltage of the oscillator.

| LabVIEW Block Diagram | NI-SYNC C Function Call |
|---|--|
|  <p>The diagram shows the 'niSync Adjust Oscillator Voltage.vi' block. It has three input terminals: 'instrument handle in' with a numeric control set to 170, 'new voltage' with a numeric control set to 2.0475, and 'error in' with an error indicator. It has two output terminals: 'error out' and 'instrument handle out' with a numeric control set to 170.</p> | <p>Call niSync_CalAdjustOscillatorVoltage with the following parameters:</p> <p>vi: "<SessionHandle>" newVoltage: <new control voltage> oldVoltage: *oldVoltage</p> |

- c. Call niSync Close External Calibration VI to commit the settings and close the session.

| LabVIEW Block Diagram | NI-SYNC C Function Call |
|---|--|
|  <p>The diagram shows the 'niSync Close External Calibration.vi' block. It has three input terminals: 'instrument handle in' with a numeric control set to 170, 'action' with a dropdown menu set to 'Commit', and 'error in' with an error indicator. It has two output terminals: 'error out' and 'instrument handle out' with a numeric control set to 170.</p> | <p>Call niSync_CloseExtCal with the following parameter:</p> <p>vi: "<SessionHandle>" action: NISYNC_VAL_EXT_CAL_COMMIT</p> |

Reverification

After completing the adjustments to the NI PXIe-6672, it is important that you verify the oscillator frequency operation by repeating the steps listed in the *Verification* section. Re-verifying after making the adjustments ensures that the NI PXIe-6672 is operating within its test limits.

National Instruments, NI, ni.com, and LabVIEW are trademarks of National Instruments Corporation. Refer to the *Terms of Use* section on ni.com/legal for more information about National Instruments trademarks. Other product and company names mentioned herein are trademarks or trade names of their respective companies. For patents covering National Instruments products, refer to the appropriate location: **Help»Patents** in your software, the `patents.txt` file on your CD, or ni.com/patents.