

## COMPREHENSIVE SERVICES

We offer competitive repair and calibration services, as well as easily accessible documentation and free downloadable resources.

## SELL YOUR SURPLUS

We buy new, used, decommissioned, and surplus parts from every NI series. We work out the best solution to suit your individual needs.

 Sell For Cash    Get Credit    Receive a Trade-In Deal

## OBSOLETE NI HARDWARE IN STOCK & READY TO SHIP

We stock **New**, **New Surplus**, **Refurbished**, and **Reconditioned** NI Hardware.



*Bridging the gap between the manufacturer and your legacy test system.*

 1-800-915-6216

 [www.apexwaves.com](http://www.apexwaves.com)

 [sales@apexwaves.com](mailto:sales@apexwaves.com)

*All trademarks, brands, and brand names are the property of their respective owners.*

**Request a Quote**

 **CLICK HERE**

**PXI-6683H**

## CALIBRATION PROCEDURE

# PXI-6683 Calibration Procedure

This document contains the verification and adjustment procedures for the PXI-6683 Series. Refer to [ni.com/calibration](https://ni.com/calibration) for more information about calibration solutions.

## Required Software

---

Calibrating the PXI-6683 Series requires you to install the following software on the calibration system:

- NI-Sync 17.0 or later.

You can download all required software from [ni.com/downloads](https://ni.com/downloads).

## Related Documentation

---

For additional information, refer to the following documents as you perform the calibration procedure:

- PXI-6683 Series Installation Guide
- PXI-6683 Series User Manual

Visit [ni.com/manuals](https://ni.com/manuals) for the latest versions of these documents.

## Test Equipment

---

The following is required equipment for the external calibration verification or adjustment of PXI-6683 Series boards:

| Equipment                  | Recommended Model(s)  | Where Used                 | Minimum Requirements  |
|----------------------------|---|----------------------------|---|
| Reference Clock            | <ul style="list-style-type: none"> <li>Symmetricon 8040C Rubidium Frequency Standard</li> <li>PXIe-6674T</li> </ul>   | Verification<br>Adjustment | <ul style="list-style-type: none"> <li>Accuracy: 100 ppb or better</li> <li>Frequency: 10 MHz</li> </ul>  |
| PXI or PXI Express Chassis | <ul style="list-style-type: none"> <li>PXI-6683 <ul style="list-style-type: none"> <li>PXIe-1065</li> <li>PXI-1045</li> <li>Any chassis with an available PXI slot.</li> </ul> </li> <li>PXI-6683H <ul style="list-style-type: none"> <li>PXIe-1065</li> <li>PXIe-1085</li> <li>Any chassis with an available PXI slot or PXI Express hybrid slot.</li> </ul> </li> </ul> | Verification<br>Adjustment | <ul style="list-style-type: none"> <li>An available slot for a PXI-6683 Series board. <ul style="list-style-type: none"> <li>PXI-6683H boards can be installed in a full PXI slot or a PXI Express hybrid slot.</li> <li>PXI-6683 Series boards require a full PXI slot.</li> </ul> </li> <li>The chassis must be able to lock its PXI_CLK10 to the 10 MHz calibration reference clock. Refer to the PXI chassis user manual for more information.</li> </ul> |

## Test Conditions

The following setup and environmental conditions are required to ensure the PXI-6683 Series board meets published specifications.

- The 10 MHz reference clock for calibration must be present at PXI\_CLK10 in the chassis being used. You can do this with one of the following methods:
  - Connect the 10 MHz reference signal directly to the 10 MHz Reference IN connector of the chassis.
  - Configure the timing and synchronization board in the timing slot of the chassis to route its CLKIN input to PXI\_CLK10\_IN.
  - Use the timing and synchronization board being calibrated to route the 10 MHz reference clock to PXI\_CLK10\_IN.
- Externally connect the ClkOut terminal of the PXI-6683 Series board to the PF10 terminal.
- Keep cabling as short as possible. Long cables and wires act as antennae, picking up extra noise that can affect measurements.
- Verify that all connections including front panel connections and screws, are secure.
- Maintain ambient temperature of  $23\text{ }^{\circ}\text{C} \pm 3\text{ }^{\circ}\text{C}$ .



**Note** Do not use the device and calibration temperature reported by MAX. The device and calibration temperature reported by MAX are the internal temperature readings of the FPGA, not the ambient temperature.

- Keep relative humidity between 10% and 90% non-condensing.

- Allow at least 15 minutes of warm-up time for the PXI-6683 Series board being calibrated.
- Allow the device providing the 10 MHz reference clock the appropriate amount of warm-up time.
  - Refer to the user manual for the device to determine the warm-up time necessary to achieve required accuracy.

## Password

---

The default password for password-protected operations is `NI`.

## Calibration Interval

---

National Instruments recommends a calibration interval of one year for the PXI-6683 Series boards. Adjust the recommended calibration interval based on the measurement accuracy demands of your application.

## PXI-6683 Series Calibration Overview

---

Install the device and configure it in Measurement & Automation Explorer (MAX).

The calibration process for PXI-6683 Series boards includes the following steps:

1. **Verification**—Verify the existing operation of the device. This step confirms whether the device is operating within the published specifications prior to adjustment.
2. **Adjustment**—Adjust the calibration constants of the device. The adjustment procedure automatically stores the calibration date on the EEPROM.
3. **Reverification**—Repeat the verification procedure to ensure that the device is operating within the published specifications after adjustment.

## Verification

---

The performance verification procedures assume that adequate traceable uncertainties are available for the calibration references.

## Verification and Measuring the Frequency

1. Initialize the PXI-6683 Series board. Set **reset device** to `True`.



**Note** If the PXI-6683 Series board to be calibrated is being used to route the 10 MHz reference signal to `PXI_CLK10_IN`, connect `CLKIN` to `PXI_CLK10_IN`.

2. Set the time reference to Free Running.
3. Using Connect Clock Terminals, route `PXI_Clk10` to BoardClk and Oscillator to ClkOut.
4. Use Measure Frequency and set the parameters in Table 1:

**Table 1. Measure Frequency Parameters**

| Parameter        | Value      |
|------------------|------------|
| decimation count | 1,000,000  |
| duration         | 10 seconds |
| source terminal  | PFI0       |

5. Close the connection to the PXI-6683 Series board.

## Comparing the Frequency

To determine if the device under test meets its specifications, you must compare the measured frequency with the specified accuracy. The following tables show the frequency range that is acceptable according to the published specifications for PXI-6683 Series boards.

**Table 2. One Year Test Limits**

| Device          | Specified Accuracy Within 1 Year of Calibration | Acceptable Frequency Range—As Found |               |
|-----------------|---|-------------------------------------|---------------|
|                 |   | Low Limit                           | High Limit    |
| PXI-6683 Series | $\pm 3.5$ ppm                                   | 9,999,965 Hz                        | 10,000,035 Hz |

**Table 3. Adjustment Target Frequency Range**

| Device          | Calibration Measurement Accuracy | Calibration Measurement Target Frequency Range—As Left |               |
|-----------------|----------------------------------|--|---------------|
|                 |                                  | Low Limit  | High Limit    |
| PXI-6683 Series | 100 ppb                          | 9,999,999 Hz   | 10,000,001 Hz |



### Note

- If the measured frequency is within the range in Table 3, you do not need to search for a new oscillator voltage. Read the current oscillator voltage from the Calibration EEPROM using `Get Oscillator Voltage`. Use this voltage value and skip to Step 4 of *Adjustment*. This will keep the same value for the oscillator voltage, but update the calibration date.
- If the accuracy of the 10 MHz oscillator is outside the specified range for the product, the device is out of calibration. A programmable voltage controls the oscillator frequency. By varying this voltage and precisely measuring the frequency, you can find a voltage that gives a frequency as close as possible to 10 MHz.

## Adjustment

This section describes the steps needed to adjust the PXI-6683 Series to meet published specifications.

# PXI-6683 Series Adjustment Procedure

A binary search algorithm may be used to find the optimal oscillator control voltage.

PXI-6683 Series boards use a 21-bit digital to analog converter (DAC) to create the oscillator control voltage, therefore at most 21 iterations of adjusting and measuring would be needed to calibrate the 10 MHz oscillator.

1. Set the oscillator control voltage. The acceptable voltage range is 0.6 V to 3 V with frequency increasing as voltage increases. Use a control voltage of 1.8 V, which is in the middle of the valid range, as a starting point.
  - a) Initialize the device.
  - b) Use the **Oscillator Voltage** property to set the oscillator voltage to 1.8 V.
  - c) Close the connection to the PXI-6683 Series board.
2. After setting the control voltage, measure the frequency again as described in [Verification and Measuring the Frequency](#).
3. If the measured frequency falls within the frequency range specified in Table 3, go to Step 4. Otherwise, repeat the first two steps of this section until the measured value falls within this range. Adjust the oscillator control voltage up to increase the frequency or down to decrease the frequency. If (measured frequency - 10 MHz) is greater than 0, the voltage needs to decrease; if (measured frequency - 10 MHz) is less than 0, the voltage needs to increase.
4. Commit the calibration values to the Calibration EEPROM.

---

## Reverification

Repeat the [Verification](#) section to determine the as-left status of the PXI-6683 Series.



**Note** If any test fails reverification after performing an adjustment, verify that you have met the test conditions before returning your PXI-6683 Series to NI. Refer to the [Worldwide Support and Services](#) section for information about support resources or service requests.

---

## Worldwide Support and Services

The NI website is your complete resource for technical support. At [ni.com/support](https://ni.com/support), you have access to everything from troubleshooting and application development self-help resources to email and phone assistance from NI Application Engineers.

Visit [ni.com/services](https://ni.com/services) for NI Factory Installation Services, repairs, extended warranty, and other services.

Visit [ni.com/register](https://ni.com/register) to register your NI product. Product registration facilitates technical support and ensures that you receive important information updates from NI.

A Declaration of Conformity (DoC) is our claim of compliance with the Council of the European Communities using the manufacturer's declaration of conformity. This system

affords the user protection for electromagnetic compatibility (EMC) and product safety. You can obtain the DoC for your product by visiting [ni.com/certification](http://ni.com/certification). If your product supports calibration, you can obtain the calibration certificate for your product at [ni.com/calibration](http://ni.com/calibration).

NI corporate headquarters is located at 11500 North Mopac Expressway, Austin, Texas, 78759-3504. NI also has offices located around the world. For telephone support in the United States, create your service request at [ni.com/support](http://ni.com/support) or dial 1 866 ASK MYNI (275 6964). For telephone support outside the United States, visit the *Worldwide Offices* section of [ni.com/niglobal](http://ni.com/niglobal) to access the branch office websites, which provide up-to-date contact information, support phone numbers, email addresses, and current events.

## Online Product Certification

---

Refer to the product Declaration of Conformity (DoC) for additional regulatory compliance information. To obtain product certifications and the DoC for this product, visit [ni.com/certification](http://ni.com/certification), search by model number or product line, and click the appropriate link in the Certification column.

Information is subject to change without notice. Refer to the *NI Trademarks and Logo Guidelines* at [ni.com/trademarks](http://ni.com/trademarks) for information on NI trademarks. Other product and company names mentioned herein are trademarks or trade names of their respective companies. For patents covering NI products/technology, refer to the appropriate location: **Help»Patents** in your software, the `patents.txt` file on your media, or the *National Instruments Patent Notice* at [ni.com/patents](http://ni.com/patents). You can find information about end-user license agreements (EULAs) and third-party legal notices in the readme file for your NI product. Refer to the *Export Compliance Information* at [ni.com/legal/export-compliance](http://ni.com/legal/export-compliance) for the NI global trade compliance policy and how to obtain relevant HTS codes, ECCNs, and other import/export data. NI MAKES NO EXPRESS OR IMPLIED WARRANTIES AS TO THE ACCURACY OF THE INFORMATION CONTAINED HEREIN AND SHALL NOT BE LIABLE FOR ANY ERRORS. U.S. Government Customers: The data contained in this manual was developed at private expense and is subject to the applicable limited rights and restricted data rights as set forth in FAR 52.227-14, DFAR 252.227-7014, and DFAR 252.227-7015.

© 2017 National Instruments. All rights reserved.

374439B-01 July 10, 2017