

COMPREHENSIVE SERVICES

We offer competitive repair and calibration services, as well as easily accessible documentation and free downloadable resources.

SELL YOUR SURPLUS

We buy new, used, decommissioned, and surplus parts from every NI series. We work out the best solution to suit your individual needs.

 Sell For Cash  Get Credit  Receive a Trade-In Deal

OBSOLETE NI HARDWARE IN STOCK & READY TO SHIP

We stock **New**, **New Surplus**, **Refurbished**, and **Reconditioned** NI Hardware.



Bridging the gap between the manufacturer and your legacy test system.

 1-800-915-6216

 www.apexwaves.com

 sales@apexwaves.com

All trademarks, brands, and brand names are the property of their respective owners.

Request a Quote

 **CLICK HERE**

PCI-5105

Manufacturer: National Instruments

Board Assembly Part Numbers (Refer to Procedure 1 for identification procedure):

Part Number and Revision	Description
196232x-03L	NI PCI-5105, 512MB/CH
196232x-02L	NI PCI-5105, 128MB/CH
196232x-01L	NI PCI-5105, 16MB/CH
195855x-03L	NI PXI-5105, 512MB/CH
195855x 02L	NI PXI -5105, 128MB/CH
195855x 01L	NI PXI -5105, 16MB/CH
156861x-03L	NI PXIe-5105, 512MB/CH
156861x-02L	NI PXIe-5105, 128MB/CH
156861x-01L	NI PXIe-5105, 16MB/CH

Volatile Memory

Target Data	Type	Size	Battery Backup	User ¹ Accessible	System Accessible	Sanitization Procedure
Waveform data	SDRAM	16 MB, 128 MB, or 512 MB	No	Yes	Yes	Cycle Power
DRAM Buffers	FPGA Block RAM	Xilinx XC2VP20 (PCI/PXI) Altera EP2S90 (PXIe)	No	Yes	Yes	Cycle Power

Non-Volatile Memory (incl. Media Storage)

Target Data	Type	Size	Battery Backup	User Accessible	System Accessible	Sanitization Procedure
Board configuration	EEPROM	8 KB (PCI/PXI) 32 MB (PXIe)	No	No	Yes	None
Device configuration	EEPROM	4 Kb	No	No	Yes	None
• Device information				No	Yes	None
• Calibration metadata				Yes	Yes	Procedure 2
• Calibration Constants ²				No	Yes	None
FPGA Programming	CPLD	Altera EPM7064 (PCI/PXI) Altera EPM240 (PXIe)	No	No	Yes	None

¹ Refer to *Terms and Definitions* section for clarification of *User* and *System Accessible*

² Calibration constants that are stored on the device include information for the device's full operating range. Any implications resulting from partial self-calibration can be eliminated by running the full self-calibration procedure.

Procedures

Procedure 1 –Board Assembly Part Number Identification:

To determine the Board Assembly Part Number and Revision, refer to the label applied to the surface of your product. The Assembly Part Number should be formatted as “P/N: #####x-##L

Procedure 2 - Device Configuration EEPROM (Calibration Metadata):

The user-accessible areas of the Device Configuration EEPROM are exposed through a calibration Applications Programming Interface (API) in LabVIEW. To clear the calibration meta-data area, complete the following steps:

1. To clear the calibration password, from LabVIEW use niScope Cal Change Password.vi to overwrite the password.
2. To clear the user-defined information, from LabVIEW use niScope Cal Store Misc Info.vi to overwrite user-defined information.

Terms and Definitions

Cycle Power:

The process of completely removing power from the device and its components and allowing for adequate discharge. This process includes a complete shutdown of the PC and/or chassis containing the device; a reboot is not sufficient for the completion of this process.

Volatile Memory:

Requires power to maintain the stored information. When power is removed from this memory, its contents are lost. This type of memory typically contains application specific data such as capture waveforms.

Non-Volatile Memory:

Power is not required to maintain the stored information. Device retains its contents when power is removed. This type of memory typically contains information necessary to boot, configure, or calibrate the product or may include device power up states.

User Accessible:

The component is read and/or write addressable such that a user can store arbitrary information to the component from the host using a publicly distributed NI tool, such as a Driver API, the System Configuration API, or MAX.

System Accessible:

The component is read and/or write addressable from the host without the need to physically alter the product.

Clearing:

Per *NIST Special Publication 800-88 Revision 1*, “clearing” is a logical technique to sanitize data in all User Accessible storage locations for protection against simple non-invasive data recovery techniques using the same interface available to the user; typically applied through the standard read and write commands to the storage device.

Sanitization:

Per *NIST Special Publication 800-88 Revision 1*, “sanitization” is a process to render access to “Target Data” on the media infeasible for a given level of effort. In this document, clearing is the degree of sanitization described.