#### **COMPREHENSIVE SERVICES**

We offer competitive repair and calibration services, as well as easily accessible documentation and free downloadable resources.

### **SELL YOUR SURPLUS**

We buy new, used, decommissioned, and surplus parts from every NI series. We work out the best solution to suit your individual needs.

Sell For Cash Get Credit Receive a Trade-In Deal

# **OBSOLETE NI HARDWARE IN STOCK & READY TO SHIP**

We stock New, New Surplus, Refurbished, and Reconditioned NI Hardware.



**Bridging the gap** between the manufacturer and your legacy test system.

0

1-800-915-6216

www.apexwaves.com

sales@apexwaves.com

All trademarks, brands, and brand names are the property of their respective owners.

Request a Quote



PCI-6561

Contact: 866-275-6964

support@ni.com



Manufacturer: National Instruments

# **Board Assembly Part Numbers** (Refer to Procedure 1 for identification procedure):

Part Number and Revision	Description
191562A-0x or later	PXI-6561/6562
191572A-0x or later	PCI-6561/6562

# **Volatile Memory**

Target Data	Туре	Size	Battery Backup	User <sup>1</sup> Accessible	System Accessible	Sanitization Procedure
Waveform data	DRAM	512 MB	No	Yes	Yes	Cycle Power
PCI communication	CHINCH	208	No	Yes	Yes	Cycle Power
	FIFO	bytes				
Buffered data	FPGA Block	720 KB	No	Yes	Yes	Cycle Power
	RAM(x1)					
Memory control	FPGA Block	112 KB	No	Yes	Yes	Cycle Power
	RAM(x2)					
daughter card data transfer	FPGA Block	864 KB	No	Yes	Yes	Cycle Power
	RAM(x1)					

# Non-Volatile Memory (incl. Media Storage)

			Battery	User	System	Sanitization
Target Data	Type	Size	Backup	Accessible	Accessible	Procedure
Device configuration	EEPROM	64 KB	No	No	No	None
Card info	Flash	32 MB	No	No	Yes	None
Program FPGAs	CPLD	64 Macro-	No	No	No	None
		cells				

<sup>&</sup>lt;sup>1</sup> Refer to Terms and Definitions section for clarification of User and System Accessible

Contact: 866-275-6964

support@ni.com



## **Procedures**

## **Procedure 1 – Board Assembly Part Number identification:**

To determine the Board Assembly Part Number and Revision, refer to the label applied to the surface of your product. The Assembly Part Number should be formatted as "P/N: ######-0#".

Contact: 866-275-6964

support@ni.com



### **Terms and Definitions**

### **Cycle Power:**

The process of completely removing power from the device and its components and allowing for adequate discharge. This process includes a complete shutdown of the PC and/or chassis containing the device; a reboot is not sufficient for the completion of this process.

## **Volatile Memory:**

Requires power to maintain the stored information. When power is removed from this memory, its contents are lost. This type of memory typically contains application specific data such as capture waveforms.

### **Non-Volatile Memory:**

Power is not required to maintain the stored information. Device retains its contents when power is removed. This type of memory typically contains information necessary to boot, configure, or calibrate the product or may include device power up states.

#### **User Accessible:**

The component is read and/or write addressable such that a user can store arbitrary information to the component from the host using a publicly distributed NI tool, such as a Driver API, the System Configuration API, or MAX.

#### **System Accessible:**

The component is read and/or write addressable from the host without the need to physically alter the product.

### **Clearing:**

Per NIST Special Publication 800-88 Revision 1, "clearing" is a logical technique to sanitize data in all User Accessible storage locations for protection against simple non-invasive data recovery techniques using the same interface available to the user; typically applied through the standard read and write commands to the storage device.

#### **Sanitization:**

Per NIST Special Publication 800-88 Revision 1, "sanitization" is a process to render access to "Target Data" on the media infeasible for a given level of effort. In this document, clearing is the degree of sanitization described.