

**Manufacturer:** National Instruments

## **Board Assembly Part Numbers** (Refer to Procedure 1 for identification procedure):

Part Number and Revision	Description
146869A-04L or later	PXIe-7861
146869A-05L or later	PXIe-7862

# **Volatile Memory**

			Battery	User <sup>1</sup>	System	Sanitization
Target Data	Type	Size	Васкир	Accessible	Accessible	Procedure
Data storage during VI	FPGA	Xilinx XC7K160T (-04I	L) No	Yes	Yes	Cycle Power
execution		Xilinx XC7K325T (-05L	ـ)			
Onboard memory	DRAM	512 MB	No	Yes	Yes	Cycle Power
storage						

# **Non-Volatile Memory**

			Battery	User	System	Sanitization
Target Data	Type	Size	Backup	Accessible	Accessible	Procedure
Device configuration	Flash	64 MB (-04L)	No			
<ul> <li>Device information</li> </ul>		128 MB (-05L)		No	Yes	None
<ul> <li>FPGA bitstream</li> </ul>				Yes	Yes	Procedure 2
<ul> <li>Calibration metadata</li> </ul>				Yes	Yes	Procedure 3
• Calibration data <sup>2</sup>				No	Yes	None

<sup>&</sup>lt;sup>1</sup> Refer to Terms and Definitions section for clarification of User and System Accessible

<sup>&</sup>lt;sup>2</sup> Calibration constants that are stored on the device include information for the device's full operating range. Any implications resulting from partial self-calibration can be eliminated by running the full self-calibration procedure.

Contact: 866-275-6964

support@ni.com



## **Procedures**

## **Procedure 1 – Board Assembly Part Number identification:**

The Assembly Part Number should be formatted as "P/N: 146869a-04L" for PXIe-7861 or "P/N: 146869a-05L" for PXIe-7862, where "a" is the letter revision of the assembly (e.g. E, F, G...).

#### **Procedure 2 - Device Configuration Flash (FPGA bitstream):**

You can use the NI-RIO Device Setup utility to erase the FPGA bitstream data. For more details, visit ni.com/info and enter the infocode fpgaflashclr.

## **Procedure 3 - Device Configuration Flash (Calibration metadata):**

The user-accessible areas of the Device Configuration Flash are exposed through a calibration Applications Programming Interface (API) in LabVIEW. For more details, visit ni.com/info and enter the infocode rseriescalclr.

Contact: 866-275-6964

support@ni.com



## **Terms and Definitions**

## **Cycle Power:**

The process of completely removing power from the device and its components and allowing for adequate discharge. This process includes a complete shutdown of the PC and/or chassis containing the device; a reboot is not sufficient for the completion of this process.

#### **Volatile Memory:**

Requires power to maintain the stored information. When power is removed from this memory, its contents are lost. This type of memory typically contains application specific data such as capture waveforms.

## **Non-Volatile Memory:**

Power is not required to maintain the stored information. Device retains its contents when power is removed. This type of memory typically contains information necessary to boot, configure, or calibrate the product or may include device power up states.

#### **User Accessible:**

The component is read and/or write addressable such that a user can store arbitrary information to the component from the host using a publicly distributed NI tool, such as a Driver API, the System Configuration API, or MAX.

## **System Accessible:**

The component is read and/or write addressable from the host without the need to physically alter the product.

#### **Clearing:**

Per NIST Special Publication 800-88 Revision 1, "clearing" is a logical technique to sanitize data in all User Accessible storage locations for protection against simple non-invasive data recovery techniques using the same interface available to the user; typically applied through the standard read and write commands to the storage device.

#### **Sanitization:**

Per NIST Special Publication 800-88 Revision 1, "sanitization" is a process to render access to "Target Data" on the media infeasible for a given level of effort. In this document, clearing is the degree of sanitization described.